


User Manual

Analog Indoor Monitor



7 Inches




4.3 Inches

Before using this product, read the Quick Guide carefully and save it for future referenceV3.0.


Front and Back Introduction

LNX-M61A



- ① Screen
- ② Monitor
- ③ Call Guard
- ④ Menu
- ⑤ Answer
- ⑥ Unlock
- ⑦ RJ45
- ⑧ Bracket Slot
- ⑨ Call Volume
- ⑩ Ringtone Volume
- ⑪ Land Doorbell Null S1 S2
- ⑫ Power Land Signal Audio
- ⑬ Speaker
- ⑭ Land Video

LNX-M16




- ① Screen
- ② Monitor
- ③ Call Guard
- ④ Menu
- ⑤ Answer
- ⑥ Unlock
- ⑦ RJ45
- ⑧ Bracket Slot
- ⑨ Land Video
- ⑩ Audio Signal Land Power
- ⑪ Call Volume
- ⑫ Ringtone Volume
- ⑬ Speaker
- ⑭ Land Doorbell Null S1 S2

Indoor Monitor Installation



Drilling

Drill screw holes at proper location for wall mounting plate.



Fix wall mounting plate


Fix the wall mounting plate to the wall with 2 screws.



Hook indoor monitor

Hang the indoor monitor on the wall mounting plate tightly.

Indoor Monitor Installation



Drilling

Drill screw holes at proper location for wall mounting plate.



Fix wall mounting plate


Fix the wall mounting plate to the wall with 2 screws.



Hook indoor monitor


Hang the indoor monitor on the wall mounting plate tightly.

Wiring Diagram(1 to 1) (Ethernet Cable)




Local LAN Networking Diagram (1 ~ 9999 Monitors)

Room number can be set 1 digit, 2 digit, 3 digit or 4 digit



network cable CAT5/CAT6 — main line in unit
 4 wires(RVV 4×1.0) — outdoor station to power
 2 wires(RVV 2×1.0) — lock to power
 2 wires(RVV 2×1.0) — exit button to power




Features

1. 7" TFT color screen.
2. Use button controls.
3. Monitor the outdoor station environment by picture and video.
4. Video call, two-way talk & intercom with outdoor station, call management center and guard station.
5. Remotely open the door with unlock button.
6. Security alarm, can be connected to two defense areas(SOS/Gas).
7. Support 9999 indoor monitors.
8. RJ45 Ethernet cable connection.
9. Call lift (requires an elevator control system).
10. Powered by POE switch.
11. Menu button: Call lift / Alarm by longtime press / Message / Photo record / Call guard station / Monitor / Unlock / Talk / Hang up.

7-inch Indoor Monitor Interface








Wiring Diagram(1 to 1) (Ethernet Cable)





Local LAN Networking Diagram (1 ~ 9999 Monitors)

Room number can be set 1 digit, 2 digit, 3 digit or 4 digit




- network cable CAT5/CAT6  main line in unit
- 4 wires(RVV 4×1.0)  outdoor station to power
- 2 wires(RVV 2×1.0)  lock to power
- 2 wires(RVV 2×1.0)  exit button to power



Features

1. 4.3" TFT color screen.
2. Use button controls.
3. Monitor the outdoor station environment by picture and video.
4. Video call, two-way talk & intercom with outdoor station, call management center and guard station.
5. Remotely open the door with unlock button.
6. Security alarm, can be connected to two defense areas(SOS/Gas).
7. Support 9999 indoor monitors.
8. RJ45 Ethernet cable connection.
9. Call lift (requires an elevator control system).
10. Powered by POE switch.
11. Menu button: Call lift / Alarm by longtime press / Message / Photo record / Call guard station / Monitor / Unlock / Talk / Hang up.

4.3-inch Indoor Monitor Interface



Specifications

Indoor Monitor(M61A)

- Display: 7-inch TFT Color Digital Screen
- Material: ABS plastic + PET
- Resolution: 800*480 Pixels
- Video Input: 1Vp-p/75Ω
- Working Voltage: DC 15-18V
- Quiescent Current: Less Than 60mA
- Working Current: Less Than 400mA
- Working Temperature: -10°C-50°C
- Dimensions: 225*140*20 (mm)
- Installation: Wall-mounted

Indoor Monitor(M16)

- Display: 4.3-inch TFT Color Digital Screen
- Material: ABS plastic + PET
- Resolution: 800*480 Pixels
- Video Input: 1Vp-p/75Ω
- Working Voltage: DC 15-18V
- Quiescent Current: Less Than 60mA
- Working Current: Less Than 400mA
- Working Temperature: -10°C-50°C
- Dimensions: 180*110*20 (mm)
- Installation: Wall-mounted

NO	Problem	Reasons	Solutions
1	The outdoor station can not call the indoor monitor.	1.Network cable problem. 2.Room number is not correct.	1.Check the network cable. 2.Set the room number.
2	No voice.	Speaker is broken.	Contact after-sales service.
3	The detector is triggered but the indoor unit does not alarm.	The connection between the detector and the indoor monitor is incorrect.	Check the connection and reconnect the detector and indoor monitor.